



ISST R32DR - Indoor Unit - Error display

Operation Lamp	Timer Lamp	Display	Error Information
1 fois	OFF	E0	Indoor unit EEPROM parameter error
2 fois		E1	Indoor / outdoor units communication error
3 fois		E2	Zero-crossing signal detection error (for 7k model)
4 fois		E3	The indoor fan speed is operating outside of the normal range
5 fois		E4	Indoor room temperature sensor T1 is in open circuit or has short circuited
6 fois		E5	Evaporator coil temperature sensor T2 is in open circuit or has short circuited
7 fois		EC	Refrigerant leak detected
9 fois		E7	Indoor unit PCB and screen Communication error
3 fois	ON	F2	Condenser coil temperature sensor T3 and T4 are in open circuit or had short circuited