




IAS482DRIV2 - Unité intérieure - Vue éclatée/ Indoor Unit - Exploded View



IAS482DRIV2	Pièces détachées/ Spare parts		
	Code	Pièces / Part Name	Quantité
2	12122500002029	Ventilation ring	1
3	12822500000450	Drainage Pan Assembly	1
3.1	17400511001044	Water Level Switch	1
4	12100103001484	Centrifugal Fan	1
5	15822500002379	Evaporator Assembly	1
5.1	15122500003256	Evaporator outlet pipe subassembly	1
5.2	15500404000005	Pipe Nut	1
5.3	15122500003257	Evaporator inlet pipe subassembly	1
5.5	15500209000002	Pin Valve	1
5.6	12222500002092	Evaporator fixing board subassembly	1
6	11002015012308	Brushless DC Motor	1
7	12222500002052	Chassis Assembly	1
8	12222500000090	Evaporator Fixing Hanger	2
9	12122500002028	Pipe fixing board subassembly	1
17	17222500A04618	Electronic control box subassembly	1
17.2	12122500002047	Insulation Plate	1
17.3	17122500A03212	Main control board subassembly	1
17.4	17400401000032	Terminal	1
17.6	11201007003424	Room Temperature Sensor	1
17.7	17400306001543	Reactor	1
17.11	1712200048868	Humidity Sensor Subassembly	1
18	12222500002033	Electric Control Box Cover	1
19	17317000A61887	Remote controller	1
20	11201007003442	Pipe Temperature Sensor	1
22	12122500002027	External Water Pump Box Assembly	1
23	11001010001757	Induction Pump	1
36	12122000029201	Bracket of Remote Controller	1
37	17317100A32766	Wired controller	1
41	12011600005258	Accessory kit	1
46	15500406000003	Flare Nut	1
46	15500406000010	Flare Nut	1