




## ISSL182DRI - Unité intérieure - Vue éclatée/ Indoor Unit - Exploded View



ISSL182DRI	Pièces détachées/ Spare parts		
	Code	Pièces / Part Name	Quantité
1	12122000A89247	Panel assembly	1
1.1	12122000A85056	Panel assembly	1
1.1.1	11002010001446	Stepper Motor	1
1.1.2	12122000A85037	Horizontal louver	1
2	12122000A83310	Panel assembly	1
3	17222000A59450	Display box subassembly	1
3.1	17122000050213	Display board subassembly	1
3.2	11201007003103	Room Temperature Sensor	1
3.3	12122000026921	Display box	1
4	12122000A89247	Panel assembly	1
5	12122000026621	Chassis support I	1
6	12122000A85080	Panel frame assembly	1
7	12122000027040	Filter filter subassembly	1
8	15822000011099	Evaporator assembly	1
9	12122000027026	pipe clamp board	1
10	12122000011994	Fixing board of fan motor	2
11	11002015011867	Brushless DC Motor	1
12	12122000000350	Bearing holder	1
13	12622000000131	Bearing components	1
14	12100102000131	Cross flow fan	1
15	12122000027029	Chassis assembly(above)	1
16	12122000027564	Chassis assembly(below)	1
16.1	12122000027039	Horizontal louver	3
16.3	12100501000032	Drain hose	1
16.7	12622000000030	Drainage plug	1
17	12222000013906	Installation plate subassembly	1
19	12122000026601	Cover of electronic control box subassembly	1
20	17222000032757	Electronic control box subassembly (Mid-and low-end)	1
20.1	12122000026606	Electronic control box subassembly	1
20.2	17122000050365	Main control board subassembly	1
20.3	11201007003445	Pipe Temperature Sensor	1
20.4	17400401000576	Wire joint	1
20.7	12122000026605	Electrical Control Box holder	1
21	17317000A61887	Remote controller	1
22	12600701000039	seal ring	1
23	12100509000061	Drain hose	1
40	12100204000685	Air freshening filter	1
42	15500209000001	Check valve	1
45	12122000029201	Bracket of remote Controller	1
46	15500406000012	Copper nut	1
46	15500406000016	Copper nut	1